

Blazing Wire Connectors™ Installation Instructions

INSTRUCTIONS FOR BVS-1:



Additional Tools Required: None.

1. Rotate wings fully apart beyond 90 degrees.
2. Insert prestripped (thick jacket 18# or 16#) or unstripped (18# or 20#) wires firmly into holes. (prestripped wires should not exceed 3/8" of exposed wire).
3. Look at the inside of the wings and make sure all 3 wires are against the wall of the connector. Squeeze the wings to the closed and locked position: You will hear the "SNAP" when the lock engages.